

Koordinater for ramme, flåte og bunnfester

Koordinater ytterpunkt ramme og flåte

Punkt	N	Ø
A1	59°20.804	05°53.607
A5	59°20.727	05°54.004
D5	59°20.526	05°53.858
D1	59°20.601	05°53.461
A	59°20.721	05°53.495
B	59°20.718	05°53.511
C	59°20.703	05°53.500
D	59°20.706	05°53.484


Koordinater bunnfester ramme (Da det er så mange bunnfester så har vi lagt inn alle ytterpunkter)

Punkt	N	Ø
1	59°20.964	05°53.712
3	59°20.976	05°53.796
5	59°20.989	05°53.907
10	59°20.933	05°54.190
11	59°20.664	05°54.420
17	59°20.430	05°54.475
18	59°20.390	05°54.389
19	59°20.262	05°53.697
23	59°20.314	05°53.465
28	59°20.523	05°53.071
33	59°20.769	05°53.274
34	59°20.800	05°53.303
35	59°20.849	05°53.349
36	59°20.920	05°53.487

Koordinater bunnfester flåte

Punkt	N	Ø
F1	59°20.803	05°53.398
F2	59°20.805	05°53.540
F3	59°20.641	05°53.908
F4	59°20.629	05°53.893
F5	59°20.603	05°53.390
F6	59°20.664	05°53.302
F7	59°20.721	05°53.296
F8	59°20.746	05°53.292

Flåter med fortøyninger



Ramme med fortøyninger

